




XTAL



BOOT




RST




MCU

CH32V103C_EVT




POWER




TOUCHKEY



平面按键 (大圆盘)




PIN




DEBUG




EEPROM



TF CARD




UART




若使用232, 则用跳冒连接3-4、5-6

LED



SPI FLASH



USB

